MARINE WINCH OPERATION GUIDE



IMPORTANT: It is the operators responsibility to determine the suitability of the equipment to its intended use. Check all applicable codes, caution and warning notations before using the product.

Keep your hands clear of the webbing or cable and its opening during operation and/or when spooling.

Do not use any Atlantic Marine Winches for lifting applications. Refer to the range of Atlantic Brake Winches range.

Our winches are **not** intended to lift, lower or transfer people at any time.

Alert all people in close proximity before use of the winch.

Keep non-operating users away from the working area of the winch.

Never winch when there are less than 3 wraps of cable or webbing on the drum at all times.

Winch out slowly and steadily. Be sure that the cable or webbing is winding evenly and tightly around the drum at all times.

Ensure cables or webbing are secured correctly before use of the winch.

Keep your clothing clear of the webbing or cable and its opening during operation and/or when spooling.

Regularly examine all parts of the winch and do not use if damaged. Repair or replace any defective parts of the winch.

Never disengage the clutch while the cable or webbing is under tension.

Never engage the clutch while the drum is rotating.

Never pull (vertically lift) more than the capacity stated on the winch.

Never use a Marine Winch to tow another vehicle or used as a load securing device ie. (boat on a trailer).

Never apply a load on the winch with the cable or webbing in full extension. Ensure at least 3 full wraps of cable or webbing are on the drum at all times.

ANOTHER QUALITY ATLANTIC PRODUCT

BRAKE WINCH OPERATION GUIDE



IMPORTANT: It is the operators responsibility to determine the suitability of the equipment to its intended use. Check all applicable codes, caution and warning notations before using the product.

Keep your hands clear of the cable, hook and its opening during operation and/or when spooling.

Tighten the brake winch handle adapter before use to ensure optimal braking ability.

Never lift more than the capacity stated on the brake winch.

Ensure cable is secured correctly before use of the brake winch.

Never winch when there are less than 3 wraps of cable on the drum at all times.

Never apply a load on the brake winch with the cable in full extension.

Ensure at least 3 full wraps of cable are on the drum at all times.

Do not lift people or lift a load over people. Alert all people in close proximity and keep non-operating users away from the working area before use of the brake winch. **Keep your clothing clear** of the cable, hook and its opening during operation and/or when spooling.

Regularly examine all parts of the brake and do not use if damaged. Repair or replace any defective parts of the winch.

Never disengage the clutch while the cable is under tension.

Never engage the clutch while the drum is rotating.

Never lubricate (grease) the braking mechanism of the brake winch

Never wrap the cable around a load as this will damage the cable.

Do not swing the load as this may cause damage.

Never leave a suspended load unattended.

ANOTHER QUALITY ATLANTIC PRODUCT